


TCL

Google TV

TCL Projector A1 P3801S

QUICK START GUIDE



Dolby Audio


HDMI™
HIGH-DEFINITION MULTIMEDIA INTERFACE

HEC Advance™

HXD401300269

BC

What's in the box




Projector x1



Remote control x1




Power cable x1



Power Adapter x1



Quick start guide x1





AAA Batteries x2

Note: The actual contents may vary depending on the country (or region) of sale. please refer to the actual product. Depending on local regulations, batteries may not be included in the package and you need to purchase batteries separately.

Getting started

Projection screen



Determine the distance between the projector and the wall or screen according to the desired screen size.

Screen Dimensions (SD)	Throw Distance (D)
45"	49.60"
50"	54.33"
60"	64.96"
70"	75.59"
80"	86.22"
90"	97.22"
100"	107.87"
110"	119.29"
120"	129.92"


Screen Dimensions (SD): The diagonal size of the projection screen (in).

Throw Distance (D): The distance between the projector and the wall or screen (in).


Note: The dimensions in the table above are for reference only, they are approximate and may slightly differ from the actual values.

Power up

Connect your power cable to the projector, then plug it in to the wall outlet.




Power your projector remote by inserting the included batteries.



Note:


- Pay attention to the positive and negative poles when installing batteries in the remote control.
- When battery leaks, immediately wipe away any fluid with a dry cloth and replace the batteries with new ones.
- Dispose of used batteries according to local waste disposal rules and regulations of the country or area you live in.

Product Overview



Note:

- Do not place objects within 8 in near the heat dissipation vents.
- Do not place any objects near the vents, as this may cause heat to build up inside the projector.
- Do not look directly into the lens so as to avoid eye damage as this projector emits strong light during use.



Note: When plugging in the power source for the first time, the power button light will flash for 3 seconds then turn solid.

- Touch the power button and all button lights will light up to activate the device.
- The button lights will remain lit for 30 seconds after the last touch.

Note: Please do not wear gloves when pressing the buttons, use your fingers to touch directly. Dry or humid weather may affect the touch effect.














Remote Control Pairing

1. Press and hold Home (🏠) and Back (←) buttons at the same time for 3 seconds.
2. The remote control light will flash red for 3 seconds, then release the buttons and wait for pairing.


Note: Keep the remote control within 12 in of the projector.

Remote control



	Power: Power on/off
	Input: Select the input source
	Focus: Adjust the picture clarity
	Google Assistant: Press the Google Assistant button on your remote to talk to Google Assistant.
	Dashboard: Access Dashboard panel
	NAVIGATION PAD: Move up, down, left, or right, then press the middle button to confirm
	Back: Return to previous screen
	HOME: Return to home screen
	Menu: Display projector settings menu
	Volume +/-: Adjust the Volume
	YouTube: Launch YouTube
	Netflix: Launch Netflix
	Prime video: Launch Prime Video


Connectivity



- ① **DC:** Connect your projector to the power source with the included power cable.
- ② **HDMI:** Connect cable box, Blu-ray player, gaming console, or other devices to your projector using HDMI cables.
- ③ **IR Sensor:** Remote control signal reception.
- ④ **USB:** Connect a USB device to access photos, music, and movies
- ⑤ **Audio Out:** The projector has a built-in speaker that can play audio, you can connect the projector to external self-powered speakers through the Audio Output port.

Power on your equipment

1. Plug in the projector. The power light turns on.
2. Press the power button on the body or remote control to turn it on.
3. The following screen appears.



4. Connect to your wireless network by selecting **Dashboard** > **Settings** > **WiFi**.


Now you can enjoy pre-installed apps on your projector.


Connect to computer or video device


1. Turn on your computer or video device.
2. Connect one end of an HDMI cable to the projector's HDMI port and the other end to an HDMI port on your video device or computer.
3. Find **Inputs** from the Home Screen or **Settings** and select **HDMI**.

Bluetooth Speaker Mode

Your projector can also be used as a speaker.

1. Press  button on the remote control to enter the projector settings menu.
2. Select **Bluetooth Speaker Mode** and turn it on.
3. Following the instruction to pair with the preferred device.

Note: If the Bluetooth connection is not established within the time specified, the projector will turn off the screen. You can press and hold  for more than 2 seconds to turn the screen back on to reconnect the Bluetooth device.

You can turn off the Light-Strip in the Bluetooth speaker mode, Go to **Settings** > **Advanced Settings** by pressing  button.

Keystones & Focus

Projector's autofocus feature ensures that the projected image is as sharp as possible without the user having to manually adjust the projector's focus.

There are three ways to enable Autofocus on TCL Smart Projector:

1. Turn on Autofocus by going to **Settings > Projector > Focus > Auto Focus**.
2. Gently move the projector to trigger the autofocus mechanism.
3. Press and hold the Focus button on the remote to trigger autofocus.

Activate manual keystone with the following steps:

Go to **Settings > Projector > Image Correction > Manual Keystone Correction**.

Note: When you power on the projector or move it to another location, the projector automatically performs keystone correction. You can turn on **Auto Keystone Correction** in projector Settings.

Ceiling installation instructions

Note: The projector accepts 1/4" thread screw for installation purposes. Do not hang anything on the projector when hanging.



Specifications

Basic information	Name	TCL Projector A1
	Model	P3801S
	Dimensions(L*W*H)	191.3*128.1*263.6 mm /75.3*50.4*103.8 in
	Weight	2.57 KG/5.7 LB
Electrical Specifications	Power Consumption	150.1 W
Optical Parameters	Resolution	1920 x 1080
	Projection ratio	1.25:1
	Focus	Auto focus
	Keystone Correction	Omni-directional auto-keystone correction
	Maximum projection size	45" -120"
System	Operating System	Android™ 11 for TV
	Connectivity	WiFi, Bluetooth 5.1, USB 2.0, HDMI, 3.5 mm output
Audio	Dolby Decoder	Dolby Audio
	Speaker Output	8W x 2
Others	Noise	<30 DB
	Operating temperature	32°F to 104°F

Troubleshooting

Fault	Solution
No image	Turn off the projector and disconnect from the power, then plug in the power cord and turn on the projector.
Image is fuzzy or blurry	<ul style="list-style-type: none">• Clean the projector lens with a soft cloth.• Use auto focus or manual focus.
No sound or the volume level is too low	<ul style="list-style-type: none">• Press volume buttons on the remote control.• Adjust the volume level of the source device.
Projector not responding to remote control	<ul style="list-style-type: none">• Check that the remote control batteries are installed correctly. If necessary, replace the batteries.• Ensure you are operating the remote control within the reception angle and range of the projector.• Note: the projector will not respond to remote commands when warming up or shutting down.
If projector has overheated and turned off	Leave off and let it cool down for about five minutes, then do the following: <ul style="list-style-type: none">• Ensure that the vents and air filter are not clogged with dust or obstructed by nearby objects.• If the problem persists, unplug the projector and restart in five minutes.
HDMI connection problem	<ul style="list-style-type: none">• Ensure the HDMI Input is selected on the projector.• Ensure the device is securely connected to the projector's HDMI port.• Remove and re-insert the power adapter from the projector.

FCC Compliance

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement

For projector: This device complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment must be installed and operated in accordance with provided instructions and the antenna(s) used for this transmitter must be installed to provide a separation distance of at least 8 in from all persons.

For remote control: The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Caution!

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

For the receiver devices associated with the operation of a licensed radio service, they bear the following statement:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and

(2) This device must accept any interference received, including interference that may cause undesired operation.

FCC ID : 2ACCJB226



WARNING: Cancer and Reproduction
Harm-www.P65Warmings.ca.gov.

BATTERY

- Risk of fire or explosion if the battery is replaced by an incorrect type. Dispose of Used Batteries According to the Instructions.
- Replacement of a battery with an incorrect type that can defeat a safeguard (for example, in the case of some lithium battery types):
- Disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, that can result in an explosion;
- Leaving a battery in an extremely high temperature surrounding environment that can result in an explosion or the leakage of flammable liquid or gas;
- A battery subjected to extremely low air pressure that may result in an explosion or the leakage of flammable liquid or gas;

1 YEAR LIMITED WARRANTY

TCL Technology Holding Limited, offers a 1 year limited warranty on selected TCL devices that are found to be defective in materials or workmanship upon submission of the following items:

1. The warranty card is properly completed and submitted, and including;
2. Proof of purchase – consisting of original invoice or sales slip indicating the date of purchase, dealer's name, model and serial number of the product.

General Terms and Conditions

This warranty is confined to the first purchaser of the product only and is not applicable to cases other than defects in material, design and workmanship.

Items and Conditions Not Covered:

Periodic checks, maintenance, repair and replacement of parts due to normal wear and tear.

Abuse or misuses, including but not solely limited to the failure to use this product for its normal purposes or in accordance with TCL's instructions on usage and maintenance.

Defects resulting from usage of the product in conjunction with accessories that are not approved by TCL for use with this product.

TCL will not be responsible for any repairs caused by third party component parts, or service that is found to be the cause for the defect or damage of the product.

Accidents, Acts of God, lightning, water, fire, public disturbances, improper ventilation, voltage fluctuations or any cause beyond the control of TCL

This warranty does not affect the consumers' statutory rights nor the consumers' rights against the dealer related to their purchase/sales agreement.

TCL's 1 Year Limited Warranty will abide by the following options regarding claims:

1. Repair the TCL product using new or previously used parts that are equivalent to new in performance and reliability
2. Replace the TCL product with the same model (or with a product that has similar functionality) formed from new and/or previously used parts that are equivalent to new in performance and reliability, also;
 - a. When a TCL product or part is replaced or provided, any replacement item becomes the customer's property and the replaced or refunded item becomes TCL's property
 - b. TCL will not provide any data transfer service. This is the customer's responsibility. TCL shall not be liable for the loss of any saved/stored data in products that are either repaired or replaced. Customer should maintain a separate backup copy of the contents of the device's data.
3. Repair or Replacement of any TCL product under the terms of this warranty does not provide right to extension or renewal of the warranty period.

4. Warranty repairs are available free of charge at TCL authorized repair centers for products that comply with the General Terms and Conditions of this warranty. Shipping cost of the defective product(s) to TCL authorized repair center is to be paid by the customer. The customer is responsible for any damage to the defective product during shipment to the authorized repair center.
5. This warranty is not transferrable. This warranty will be the purchasers' sole and exclusive remedy and neither TCL nor its service centers shall be liable for any incidental or consequential damages or breach of any express or implied warranty of this product.
6. This warranty extends to products purchased and sold within the United States and Canada. All products sold in United States will be subject to their respective state and federal laws. All products purchased in Canada will be subject to Canadian laws.

For more information on warranty of your device, please visit our website: <https://www.tcl.com>

Google TV is the name of this device's software experience and a trademark of Google LLC. Google, YouTube and Android are trademarks of Google LLC.

Netflix is a trademark of Netflix, Inc. Manufactured under license from Dolby Laboratories. Dolby, Dolby Audio and the double-D symbol are trademarks of Dolby Laboratories Licensing Corporation.

The terms HDMI, HDMI High-Definition Multimedia interface, HDMI Trade dress and the HDMI Logos are trademarks or registered trademarks of HDMI Licensing Administrator, Inc.

All brands contained herein are trademarks of their respective owners.