




What's in the Box




Specification

Model : RT-GX1
 Model Name : UHD Streamer
 CPU : Realtek RTD1325 A55
 Memory : 4GB DDR4
 Storage : 32GB eMMC 5.1


Input : DC 12V = 1A
 Operating System : Android TV™ OS
 Wi-Fi : 2.4/5GHz (2R2T), 802.11 ax (WiFi 6)
 Bluetooth : Bluetooth 5.2
 Remote : IR & BT with voice control

About Your GX1



- 1 Indicator Light**
Glow blue when the GX1 is on. Glow white in standby mode.
- 2 Optical Port**
Optical digital audio connections are a way to send high-quality audio.
- 3 AV Port**
Supports only standard RCA terminal definition for a traditional television.
- 4 HDMI 2.1 Port**
Connect GX1 to the HDMI port of an HD or UHD TV with a HDMI cable.
- 5 Ethernet Port**
Connect your GX1 to a wired network with an Ethernet cable (not included).
- 6 DC Power**
Connect GX1 to your AC power source with the included power adapter.
- 7 USB 2.0**
Connect to your device such as external storage, gamepad, webcam, air mouse, and more.

About Your Remote



Let's Get Started




- 1** Connect the GX1 to AC power using the included power adapter. The GX1's status light will automatically glow blue when powered on.
- 2** Connect the GX1 to the TV using an HDMI or RCA cable.
- 3** Pair the remote with the GX1, then connect to your home internet (wired/WiFi).
- 4** Start streaming!

Remote Control Pairing

After connecting the device, press the Home button and Back button simultaneously for 5 seconds on the first screen. The Bluetooth remote control will connect automatically please check the message on a screen that has been paired.

Device Pairing Settings

Once the device's initial setup is complete, follow the steps below to connect additional Bluetooth devices such as game controllers or earphones.



Data Protection

Please be aware that RockTek, its manufacturing partners, application providers, and service providers may collect and use technical data and related information, including but not limited to information about this device, system and application software, and peripherals. This information may be used to improve products or provide services or technologies to you, as long as it is in a form that does not personally identify you. Additionally, please note that some services, whether pre-installed or installed by you, may require registration and the provision of personal data. Furthermore, some non-pre-installed services that you choose to install may collect personal data without additional warnings. RockTek cannot be held liable for any potential data protection breaches by services that are not pre-installed.


Safety

- CAUTION** Misuse or improper use of the device may cause electric shock or damage to properties.
- Use only the power cable that comes with the product
- Do not touch the power plug with wet hands.
- Do not install the device in areas with excessive moisture or dust, or where the temperature is high.
- Do not plug multiple devices into a single outlet.
- Do not turn off the device while it is updating the system.
- Unplug the device during severe lightning or thunder, and when you are not using it for an extended period.

CAUTION This lightning flash with arrowhead symbol with an equilateral triangle is intended to alert the user to the presence of non-insulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to pose a risk of electric shock. Warning: To reduce the risk of electric shock, do not remove the cover (or back) as there are no user-serviceable parts inside. Refer servicing to qualified personnel. The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance instructions in the literature accompanying the appliance.


WEEE Directive
 Correct Disposal of This Product. This marking indicates that this product should not be disposed of with other household waste throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can ensure this product for environmentally safe recycling.

Remote Control Pairing



Device Pairing Settings

Settings → Scroll down → Remote & Accessories. Then, proceed to pair the desired device by selecting "Accessory pairing".



Data Protection

Please be aware that RockTek, its manufacturing partners, application providers, and service providers may collect and use technical data and related information, including but not limited to information about this device, system and application software, and peripherals. This information may be used to improve products or provide services or technologies to you, as long as it is in a form that does not personally identify you. Additionally, please note that some services, whether pre-installed or installed by you, may require registration and the provision of personal data. Furthermore, some non-pre-installed services that you choose to install may collect personal data without additional warnings. RockTek cannot be held liable for any potential data protection breaches by services that are not pre-installed.

Safety

- CAUTION** Misuse or improper use of the device may cause electric shock or damage to properties.
- Use only the power cable that comes with the product
- Do not touch the power plug with wet hands.
- Do not install the device in areas with excessive moisture or dust, or where the temperature is high.
- Do not plug multiple devices into a single outlet.
- Do not turn off the device while it is updating the system.
- Unplug the device during severe lightning or thunder, and when you are not using it for an extended period.

CAUTION This lightning flash with arrowhead symbol with an equilateral triangle is intended to alert the user to the presence of non-insulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to pose a risk of electric shock. Warning: To reduce the risk of electric shock, do not remove the cover (or back) as there are no user-serviceable parts inside. Refer servicing to qualified personnel. The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance instructions in the literature accompanying the appliance.

WEEE Directive
 Correct Disposal of This Product. This marking indicates that this product should not be disposed of with other household waste throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can ensure this product for environmentally safe recycling.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help.
- To assure continued compliance, any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.
 (Example - use only shielded interface cables when connecting to computer or peripheral devices).
 This equipment complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
 (1) This device may not cause harmful interference, and
 (2) This device must accept any interference received, including interference that may cause undesired operation.

FCC Radiation Exposure Statement:
 The equipment complies with FCC Radiation exposure limits set forth for uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20 cm between the radiator and your body.

Dolby VISION-ATMOS
 Dolby, Dolby Vision, Dolby Atmos, and the double-D symbol are registered trademarks of Dolby Laboratories Licensing Corporation. Manufactured under license from Dolby Laboratories. Confidential unpublished works. Copyright © 2012-2024 Dolby Laboratories. All rights reserved.

HDMI™
 The terms HDMI, HDMI High-Definition Multimedia Interface, HDMI Trade dress and the HDMI Logos are trademarks or registered trademarks of HDMI Licensing Administrator, Inc.

Google TV is the name of this device's software experience and a trademark of Google LLC. Google, YouTube, Android TV and YouTube Music are trademarks of Google LLC.




盤點您的裝備



規格


型號：RT-GX1	額定電壓/電流：DC 12V=1A
產品名稱：UHD Streamer	Wi-Fi：2.4/5GHz (2R2T), 802.11 ax (WiFi 6)
作業系統：Android TV™ OS	藍牙：Bluetooth 5.2
CPU：Realtek RTD1325 A55	遙控器：IR & BT(語音控制)
記憶體：4GB DDR4	製造原產地：中國
儲存容量：32GB eMMC 5.1	

認識GX1



- 1 電源指示燈**
開機狀態顯示藍光指示燈，待機狀態顯示白光指示燈。
- 2 Optical孔**
高品質光纖音源輸出孔，可接上您的家庭劇院組。
- 3 AV孔**
支援三色RCA端子輸出影像以及音頻輸出。
- 4 HDMI 2.1孔**
建議的高畫質影像和聲音輸出方式，請將HDMI線連接GX1與電視螢幕。
- 5 有線網路孔**
如未使用無線網路時可使用有線網路。
- 6 電源孔**
請將內附的電源供應器連接GX1與電視螢幕。
- 7 USB 2.0**
連接您的USB裝置如隨身碟、外接硬碟、搖桿、視訊鏡頭、飛鼠鍵盤、滑鼠、鍵盤...

認識遙控器



讓我們開始吧




- 1 連接電源供應器，GX1 亮起藍色指示燈
- 2 將HDMI線或AV端子線連接上電視和 GX1 上
- 3 將遙控器與 GX1 配對，然後連接到您的網路(有線/WiFi)
- 4 開始觀看!

配對遙控器

在連接設備之後，同時按住首頁鍵 和返回鍵 約5秒鐘。

藍牙遙控器會自動連接，依照畫面指示，等待幾秒鐘後並停止按任何按鈕，直到畫面彈出“連線成功”。



遙控器與其他設備配對設定

設備的初始設定完成後，按照以下步驟連接其他藍牙設備，如遊戲搖桿或音響。

設定 → 滾動到底部
→ 點選 "遙控器與配件"
→ +與配件配對 → 選擇
您所要配對的設備名稱。



聯絡我們

委製造商：雷爵科技股份有限公司
地址：彰化市中央路184號16樓之9
電話：(04)762-9935
官網：RockTek.com.tw
(週一~週五 09:30~12:00,13:30~18:00)
客服信箱：support@rocktek.com.tw

警語

取得審驗證明之低功率射頻器材，非經核准，公司、商號或使用者均不得擅自變更頻率、加大功率或變更原設計之特性及功能。
低功率射頻器材之使用不得影響飛航安全及干擾合法通信；經發現有干擾現象時，應立即停用，並改善至無干擾時方得繼續使用。
前述合法通信，指依電信管理法規定作業之無線電通信。
低功率射頻器材須忍受合法通信或工業、科學及醫療用電波輻射性電機設備之干擾。



Dolby, Dolby Vision, Dolby Atmos, and the double-D symbol are registered trademarks of Dolby Laboratories Licensing Corporation. Manufactured under license from Dolby Laboratories. Confidential unpublished works. Copyright © 2012–2024 Dolby Laboratories. All rights reserved.

The terms HDMI, HDMI High-Definition Multimedia Interface, HDMI Trade dress and the HDMI Logos are trademarks or registered trademarks of HDMI Licensing Administrator, Inc.

Google TV 是這部裝置軟體服務的名稱，也是 Google LLC 的商標。Google、YouTube、Android TV 和 YouTube Music 是 Google LLC 的商標。

設備名稱：UHD Streamer Equipment name		型號(型式)：GX1 Type designation (Type)				
單元 Unit	限用物質及其化學符號 Restricted substances and its chemical symbols					
	鉛Lead (Pb)	汞Mercury (Hg)	鎘Cadmium (Cd)	六價鉻Hexavalent chromium (Cr+6)	溴Bromine (Br)	
外殼	○	○	○	○	○	
電路板	○	○	○	○	—	
遙控器	○	○	○	○	○	
HDMI線	○	○	○	○	○	

備考1. "超出0.1 wt %"及"超出0.01 wt %"係指限用物質之百分比含量超出百分比含量基準值。
Note 1: "Exceeding 0.1 wt %" and "exceeding 0.01 wt %" indicate that the percentage content of the restricted substance exceeds the reference percentage value of presence condition.

備考2. "○"係指該項限用物質之百分比含量未超出百分比含量基準值。
Note 2: "○" indicates that the percentage content of the restricted substance does not exceed the percentage of reference value of presence.

備考3. "—"係指該項限用物質為排除項目。
Note 3: The "-" indicates that the restricted substance corresponds to the exemption.